

Használati útmutató

dyras

Ébresztőóra

Modell: ALCL-711



Kérjük, használat előtt figyelmesen olvassa el a használati útmutatót!

BIZTONSÁGI TUDNIVALÓK

Kérjük, használatba vétel előtt gondosan tanulmányozza át, és kövesse ezt a kezelési útmutatót. A készülék működtetése során az alábbiakban felsorolt biztonsági intézkedéseket feltétlenül be kell tartani.

- Ezt a készüléket nem szánták csökkent fizikai, érzékelési vagy szellemi képességű, illetve tapasztalattal vagy ismerettel nem rendelkező személyek általi használatra (beleértve a gyermekeket is), kivéve, ha egy olyan személy felügyeli vagy tájékoztatja őket a készülék használatát illetően, aki egyben felelős a biztonságukért is. Gyermekek esetében ajánlatos a felügyelet, azért, hogy biztosítsák, hogy a gyermekek ne játszanak a készülékkel. 14 éves kor alatti gyermekek a terméket nem használhatják még felügyelet mellett sem!
- A gyártó által a készülékhez nem mellékelte vagy nem javasolt eszközök, kiegészítők használata nem megengedett. Ezek alkalmazása balesetet vagy rendellenes működést okozhat.
- Ne helyezze a készüléket forró tárgyak közelébe (pl. tűzhely, fűtőtest stb.), vagy meleg felületre, illetve olyan helyre, ahonnan legurulhat, leeshet, vagy ahonnan lerántható, leverhető egy véletlen mozdulattal.
- Ne használja a készüléket robbanékony vagy gyúlékony gázok, gőzök vagy folyadékok jelenlétében.
- A készülék csak az itt leírt háztartási használatra szolgál, minden egyéb (iparszerű) felhasználás tilos!
- A készüléket vízbe vagy más folyadékba meríteni tilos! Ha a készülék belsejébe nedvesség kerül, az meghibásodást okozhat, ezért ne használja olyan helyen, ahol a levegő páratartalma magas!
- Lemerült elemet ne hagyjon a készülékben állni, azt mindig vegye ki a készülékből!

FUNKCIÓK

- 4 számjegyű LED kijelző, 5 normál kijelző mód: óra, dátum, hőmérséklet, éjjeli mód, ébresztőóra; 5 gomb: Ébresztőóra, Mód, Fel, Le, Szundi mód
- Idő kijelző funkció
- Dátum funkció
- Hőmérséklet funkció
- Éjszakai zavarásgátló funkció: A „Snooze” gombot több mint 3 másodpercig lenyomva kikapcsolhatja a kijelzőt, hogy megakadályozza, hogy a fényes képernyő megzavarja az alvást. A kikapcsolt képernyő üzemmódba való belépést követően bármelyik gomb megnyomásával megnyithatja a kijelzőt.
- Ébresztés funkció
- Energiatakarékos mód: amikor elemmel működteti a készüléket, bármely üzemmód esetén a LED kijelző automatikusan kikapcsol 16 másodperc után és bekapcsol az energiatakarékos mód. Az óra és hőmérséklet funkciók továbbra is működnek és minden beállítás megmarad.
- 3 szintű fényerősség választ: nyomja meg az „Up” gombot a fényerősség választásához.
- Automatikus fényesség állítás funkció: a fényerő automatikusan csökken 18:00 és 6:00 közt; a fényerő állítható.
- Idő megjegyzés funkció (3xAAA elemmel működésnél)
- Hangvezérlő funkció: amikor elemmel használja a készüléket, a kijelzőt hanggal is tudja aktiválni és a kijelző automatikusan kikapcsol 16 másodperc után.

MŰKÖDÉSI ÚTMUTATÓ

Kapcsolja be a készüléket és a LED kijelző 2 másodperc után bekapcsol. Az alapértelmezett rendszer: 24 órás formátum.

Az idő beállítása

1. Nyomja le és tartsa nyomva a Mode gombot, majd válasszon a 12 órás vagy 24 órás formátum között.
2. Nyomja meg a Mode gombot és állítsa be az órát az Up/Down gombok segítségével.
3. Nyomja meg a Mode gombot és állítsa be a percet az Up/Down gombokkal.
4. Nyomja meg a Mode gombot a kilépéshez.

A dátum beállítása

1. Nyomja meg a Mode gombot egyszer, hogy megnyissa a dátum beállítót. Nyomja meg és tartsa nyomva a Mode gombot, majd állítsa be az évet az Up/Down gombok segítségével.
2. Nyomja meg a Mode gombot, majd állítsa be a hónapot az Up/Down gombokkal.
3. Nyomja meg a Mode gombot és állítsa be a megfelelő napot az Up/Down gombokkal.
4. Nyomja meg a Mode gombot a kilépéshez.

A hőmérséklet beállítása

1. Nyomja meg kétszer a Mode gombot.
2. Nyomja meg a Down gombok a °C/°F kiválasztásához.
3. Nyomja meg és tartsa nyomva a Mode gombot, amíg egy sípolást nem hall. Váltson vissza LED-re, hogy a kijelzőn sorban láthassa az időt (10 másodperc), dátumot és a hőmérsékletet (3-3 mp).
4. Nyomja meg a Mode gombot a kilépéshez.

Az éjszakai mód beállítása

1. Nyomja meg a Mode gombot háromszor. A kijelzőn megjelenik az OFF felirat.
2. Nyomja meg az Up/Down gombot az éjszakai mód ki/bekapcsolásához.
3. Nyomja le és tartsa nyomva a Mode gombot, majd állítsa be az éjszakai mód kezdetének óráját.
4. Nyomja meg a Mode gombot és állítsa be az éjszakai mód kezdésének percét.
5. Nyomja meg a Mode gombot, hogy beállíthassa az éjszakai mód végének óráját.
6. Nyomja meg a Mode gombot és állítsa be az éjszakai mód végének percét.
7. Nyomja meg a Mode gombot a kilépéshez.

Az ébresztő beállítása

1. Nyomja meg az Alarm gombot bármelyik módban, majd nyomja meg az Alarm gombot az ébresztő ki/bekapcsolásához.
2. Bármely módban nyomja le és tartsa nyomva az Alarm gombot és állítsa be az ébresztés óráját.
3. Nyomja meg az Alarm gombot és állítsa be az ébresztés percét.
4. Nyomja meg az Alarm gombot, hogy beállítsa a szundi idejét.
5. Nyomja meg az Alarm gombot és állítsa be a munkanapokat az Up/Down gombokkal.
 - a. 1-5: hétfő – péntek
 - b. 1-6: hétfő – szombat
 - c. 1-7: hétfő – vasárnap

FIGYELEM

- Kerülje az ébresztőóra leejtését vagy megütését.
- Ha szükséges, tiszta, száraz ruhával törölje le a felületét!
- Ne mossa le az órát vízzel, mert az óra szerkezete megsérülhet, ha vízbe meríti!

MŰSZAKI ADATOK

Modell: ALCL-711

- Feszültség: DC 5V
- Tápellátás: 3xAAA

HULLADÉKKEZELÉS

Használt elektromos és elektronikus berendezések megsemmisítése



Ez a jelzés a terméken és a csomagoláson azt jelzi, hogy tilos háztartási hulladék közé dobni a már nem használt terméket mivel kifejezetten környezetszennyező. További részletekkel kapcsolatban érdeklődjön a helyi hatóságnál. Ez a jelzés az Európai Unió teljes területére érvényes. Amennyiben az Európai Unión kívül szeretné megsemmisíteni a terméket érdeklődjön az ezzel kapcsolatos szabályzásokról a helyi hatóságnál.

Gyártó/Importőr: Vöröskő Kft., 8200 Veszprém, Pápai út 36.

A CE SZIMBÓLUM



A CE jelölés azt hivatott jelezni, hogy a termék a rá vonatkozó európai uniós előírásoknak megfelel és szabadon forgalmazható az Európai Unió területén.

Instruction manual

dyras

Alarm Clock

Model: ALCL-711



Before using this device, please read the instruction manual carefully.

IMPORTANT SAFETY INFORMATION

Please read the user manual thoroughly before using your new appliance. You must obey the safety instructions that follow when using the appliance.

- This device is not supposed to be used by physically or mentally handicapped people, or persons without experience or knowledge (including children), unless their use of the device is supervised or guided by someone who is at the same time responsible for their safety. As for children, supervision is recommended to make sure that they do not play with the device. This device is not supposed to be used by children under the age of 14, not even with supervision!
- Never use an appliance or accessory that the manufacturer did not supply with, or propose for use with, the appliance. The use of such appliances or accessories might lead to accidents or irregular function.
- Do not place the appliance near hot objects (e.g., electric or gas cooker, hob, radiator, etc.) or on a hot surface and do not use the appliance on an unstable surface, or a high surface, or any surface where it is unstable and can be knocked down in an accident.
- Do not use the appliance in the presence of explosive or inflammable gases, vapours or liquids.
- This device is intended only for household use. Do not use for industrial or retail purposes.
- Do not immerse the appliance in water or any other liquid! If humidity gets into the appliance, it can cause defects, so do not use it in the bathroom or any other room where there is high humidity.
- Always remove the battery when it stops working. Never leave a dead ("flat") battery in the appliance.

FUNCTION INTRODUCTION

- 4-digit LED display, 5 normal display modes: clock, date, temperature, night, alarm; 5 key operations: Alarm, Mode, Up, Down, Snooze/Light
- Time display function
- Date function
- Temperature function
- Nighttime anti-disturbance function: In the non-setting state, you can press and hold the Snooze button for more than 3 sec to turn off the display to prevent nighttime bright screen from disturbing sleep. After entering the off-screen mode, you can press any key to open the display.
- Alarm function
- Power saving function: when powered by battery, in any mode the LED display will automatically turn off for about 16 sec without a button and enter the power saving mode, but the system still maintains normal timing and temperature and save the previous settings.
- 3-level brightness adjustment: press the up key to adjust the 3-level brightness
- Automatic brightness adjustment function: the brightness is automatically dimmed from 18:00 to 6:00 and the automatic brightness interval can be set
- Time memory function (3 AAA battery drivers)
- Voice control function: when using dry battery, the display can be voice-activated and automatically turned off after 16 sec.

OPERATING INSTRUCTION

Power-on the device and the LED is fully displayed for about 2 seconds. The default system: 24-hour system.

Setting the time

1. Press and hold the Mode button and choose between the 24h or 12h format.
2. Press the Mode button and complete the hour setting with the Up/Down button.
3. Press mode button and complete the minute setting with the Up/Down buttons.
4. Press the Mode button to returning to the time mode.

Setting the date

1. Press the mode button once to open the date mode. Press and hold the Mode button and complete the year setting with the Up/Down buttons.
2. Press the Mode button to choose the month with the Up/Down buttons.
3. Press the Mode button and complete the date setting with the Up/Down buttons.
4. Press the Mode button again to return to time mode.

Setting the temperature

1. Press the Mode button twice.
2. Press the down button for the °C/°F conversion.
3. Press and hold the Mode button until there is a “Beep” sound. Switch to LED to display the time (10 sec), date (3 sec) and temperature (3 sec) in turn.
4. Press the Mode button to returning the time mode.

Setting the night mode

1. Press the Mode button 3 times. The “OFF” will flash.
2. Press Up/Down to turn on/off the night mode.
3. Press and hold the Mode button and complete the start time setting with the Up/Down buttons.
4. Press the Mode button and complete the start minute setting with the Up/Down button.

5. Press the Mode button to complete the end time setting with the Up/Down.
6. Press Mode and complete the end minute setting with the Up/Down.

Setting alarm mode

1. Press the Alarm button in any mode to display the alarm mode. Press the Alarm button to turn on/off the alarm.
2. In any mode, press and hold the Alarm button and complete the time setting with the Up/Down.
3. Press the Alarm button and complete the minute setting with the Up/Down buttons.
4. Press the Alarm to complete the snooze time setting with the Up/Down button.
5. Press the alarm and complete the working day alarm setting with the Up/Down buttons.
 - a. 1-5: Monday – Friday
 - b. 1-6: Monday – Saturday
 - c. 1-7: Monday – Sunday

ATTENTION

- Avoid dropping or hitting the clock.
- Wipe clock surface with a clean dry cloth if need clean.
- Do not wash the clock with water, the clock mechanism can be damaged if immersed in water.

SPECIFICATIONS

Model: ALCL-711

- Voltage: DC 5V
- Battery: 3xAAA

WASTE MANAGEMENT

Correct Disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Manufacturer/Importer: Vöröskő Kft., 8200 Veszprém, Pápai út 36.

THE CE SYMBOL



The CE mark is intended to indicate that the product complies with the relevant European Union standards and can be freely marketed in the European Union.

dyras

www.dyras.hu

Copyright © 2023 The dyras wwe.factory LLC U.S.A.

No parts of the content (including logos, design, photos, text, colour scheme arrangements, etc.) may be reproduced, reused or redistributed for any purpose whatsoever, or distributed to a thirdparty for such purposes, without the written permission of The dyras wwe.factory LLC.

®= registered trademark of Dyras Europe Kft.